

Raising an item

Ensure the hooks are properly located and the cord is not twisted before pulling on the cord. The auto-locking device will hold the item suspended with each pull. Once hoisted to the correct height, wrap the excess cord securely around the cleat. Do not cut excess cord

Lowering an item

Pull the cord toward the rear pulley while maintaining tension on the cord. This will release the auto-locking mechanism so the weight of the item will now cause the item to lower. Keeping the tension in this direction, slowly let the cord out as the item lowers. Once low enough, remove it from the hooks and wrap the cord back on the cleat.

For hoisting some items, like Kayaks, it may be necessary in addition to use a suitable strap system with the hooks.

